





HOME ELEGANCE

# ASSEMBLING INSTRUCTIONS


ITEM NO: 9479SDB-2 DOUBLE RECLINING LOVE SEAT WITH CENTER CONSOLE

CONSOLE BACK REST IS STORED IN THE BOTTOM OF THE SEAT, PLESAE TAKE OUT FOR ASSEMBLY.

NO.	PARTS LIST	QTY	DESCRIPTION
A		1	SEAT
B		1	LSF BACK REST
C		1	RSF BACK REST
D		1	CONSOLE BACK REST
E		1	LSF EAR
F		1	RSF EAR


NO.	HARDWARE LIST	QTY	DESCRIPTION
G		2	BOLT

STEP 1



Take out Console back rest for assembly

STEP 2





HOME ELEGANCE


# ASSEMBLING INSTRUCTIONS

ITEM NO: 9479SDB-2 DOUBLE RECLINING LOVE SEAT WITH CENTER CONSOLE


Step 3 # Align the femal metal bracket at the back onto the male metal bracket at the seat, insert back rest to the seat then push to the end and make sure it is fixed in position securely.

Step 4 # Align the metal bracket at the ear onto the male metal bracket at the back rest, push the ear down and make sune it is fixed in position securely.


## STEP 3



## STEP 4



## Step 5 # Completed



### CARE INTRUCTION POLYESTER FURNITURE

In order to maintain the original appearance of your polyester furniture, please follow below simple care procedures.

°Avoid exposing polyester furniture directly to sunlight or heating and air conditioning outlets. Exposure to sunlight or heating and air conditioning outlets will fade/damage polyester furniture.

°Wipe gently with a damp soft cloth to remove dust , dirt and any grime build up.