

# Assembly Instruction






ITEM NO.: 8348BLK-3

Double Reclining Sofa with cup holders




Note: Do not use power tools for assembly. Power tools increase the risk of over tightening which leads to splitting or cracking the wood.


## COMPONENT LIST

| No       | Drawing                                                                             | Description             | Qty  |
|----------|-------------------------------------------------------------------------------------|-------------------------|------|
| <b>A</b> |   | <b>SEAT</b>             | 1 PC |
| <b>B</b> |  | <b>LSF BACK REST</b>    | 1 PC |
| <b>C</b> |  | <b>MIDDLE BACK REST</b> | 1 PC |
| <b>D</b> |  | <b>RSF BACK REST</b>    | 1 PC |
| <b>E</b> |  | <b>LSF EAR</b>          | 1 PC |
| <b>F</b> |  | <b>RSF EAR</b>          | 1 PC |


## Step #1




## Step #2



## Step #3



## COMPLETED



## Care Instruction for Corduroy Furniture:

In order to maintain the original appearance of your Corduroy Furniture, please follow below simple care procedures:

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Sunlight and or exposure to heating and air conditioning outlets will fade/damage Corduroy.
- Vacuum or wipe with a soft cloth to remove dust.
- Hardware may loosen over time. Periodically check to make sure all connections are tight, Re-tighten if necessary.



For items use on wooden floors, hard surfaces or carpets, it is recommended to install protective pads under all legs and supports to avoid/prevent from damage/scratches and discoloration.