




Assembly Instruction

CHAISE, 100% POLYESTER

ITEM NO.: 8469-5

NO	DRAWING	QTY	DESCRIPTION
A		1	CHAISE
B		2	FRONT LEG
C		2	REAR LEG
D		4	BOLT
E		4	WASHER
F		4	SRING WASHER
G		1	ALLEN


Step#1 Take out the legs and hardware from the bottom of the chaise for assembly.




Step#2 Legs assembly please follow the drawing.

Align the front legs and rotate to tighten it in secured and correct position.

Align the rear legs to the position, the curve must facing outward, insert the bolts and washers then tighten with Allen Key.



Step#3 Place the chaise with upright position.



Care instruction for 100% polyester furniture.

In order to maintain the original appearance of your 100% polyester furniture, please follow below simple care procedures:

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Sunlight and/or exposure to heating and air conditioning outlets will fade/damage fabrics. Do not place your upholstered furniture too close to windows, radiators, or vents, and be sure to use windows, radiators, or vents.
- Vacuum or wipe with a cloth regularly to remove dust.
- Clean 100% polyester furniture with professional cleanser.